

MXOHO — Wardrobe Installation Manual

For MXOHO sliding & hinged wardrobe systems · EN-V1.0 · 2026

1. Tools Required

Spirit level / Tape measure / Cordless drill / Rubber mallet / Screwdrivers / Diagonal measure / PTFE dry spray / Stepladder / Helper (mandatory for tall units)

2. Before You Start

- Verify all panels, shelves, rails and hardware against the packing list.
- Check ceiling height matches the order; tall units need ceiling clearance during tilting.
- Acclimatise panels in the room for 24–48 hours before assembly.

3. Carcass Assembly (Upright Method)

- 1 Lay the bottom board on protective card; attach both side panels with cam locks.
- 2 Insert the centre vertical dividers, then lock the top board.
- 3 Square the carcass with a diagonal measure before fitting the back panel.
- 4 Nail or screw the back panel every 200 mm — it is the main shear stiffener.
- 5 Stand the carcass upright with two people; level with adjustable feet.
- 6 Fix the top to the wall with the supplied L-brackets and anchors.

TROPICAL TIP: Leave 10 mm between the back panel and wall for airflow, and never stand the carcass directly on a wet floor — use the plinth or adjustable feet.

4. Shelves, Rails & Drawers

- 1 Insert shelf pins and set shelves level; respect maximum spans for heavy loads.
- 2 Fix the clothes rail into its flanged sockets; test with a loaded hanger.
- 3 Assemble drawers flat; check the diagonal before inserting runners.
- 4 Clip runners onto the carcass and tune soft-close action.

5. Sliding Door Fitting (if applicable)

- 1 Fix the top track level — sliding action depends entirely on track accuracy.
- 2 Hook top rollers first, then snap the bottom guides into place.

-
- | | |
|-------|---|
| 3 | Adjust roller height so doors hang plumb with an even 3 mm overlap gap. |
| <hr/> | |
| 4 | Fit anti-jump blocks and bottom guide retainers. |

6. Hinge & Handle Adjustment

- Set even 2–3 mm door gaps with the hinge cam screw; align faces with the depth screw.
- Torque handle setscrews firmly but do not over-tighten into board cores.
- Lubricate sliding tracks with dry PTFE spray only — never oil (attracts dust).

7. Warranty Statement

- Wall paint & electrical circuits: 5 years warranty.
- Cabinet body: 3 years warranty.
- Hardware: lifetime free repair & replacement for non-human damage.
- Cabinet lights and electrical accessories: excluded from warranty.
- This warranty applies from the installation date and covers manufacturing defects only. Damage caused by incorrect installation, standing water, or use outside the specified indoor environment is not covered. Claims require photographs, the packing list and installation date.